



INSTALLATION GUIDE

CTS Turbo Audi 8V RS3 2.5T
EA855 Turbo Outlet Pipe
CTS-IT-259



20630 Mufford Crescent, Unit #309
Langley, British Columbia V2Y 2V9

www.CTSTURBO.com

WHAT IS INCLUDED

1. CTS Turbo Throttle Pipe

**TOOLS REQUIRED**

1. 10mm Triple square
2. T30 Torx
3. Ratchet
4. Socket extension
5. Pliers

NOTES

Vehicle used in this guide is a 2017 Audi RS3. Always make sure the car is safe to work on. Do not work on a hot motor. We do not accept any liability for incorrect installation or damage during the install.

STEP 1

Begin by raising the car up to gain access to the bottom.

Remove the belly pan

**STEP 2**

Use a T30 torx to release the bottom end of the stock turbo outlet pipe.




STEP 3

Remove the bolt at the top of the turbo outlet pipe using a 10mm triple square.

**STEP 4**

Undo the hose clamp at the end of the silicone connector closest to the turbo



STEP 5

You should now be able to take the stock turbo outlet pipe from the engine bay.

**STEP 6**

Transfer to stock silicone connector to the CTS Turbo Outlet Pipe and secure with the hose clamp.



STEP 7

Install the CTS pipe and secure the top and bottom using the hose clamps and secure the pipe in the centre with the 10mm triple square you removed earlier.

